

---

Subject: Text counters filled in

Posted by [wanderingwonder](#) on Sun, 06 Nov 2011 18:58:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I uploaded a model with beveled text. It contains an A, R and d. The counters (inner closed areas of text) on the A and the R are filled in, but not the d. It's not like that when I look at the file on my computer, only after upload. Any ideas what could cause that? Any help would be appreciated. Thanks!

---